


FIGURE 1



61	Receiver software routines
65	Search for signal
66	Decode RDS data
67	Filter RDS groups
68	Format data
64	Output serial data
69	Receiver control

RDS —

RDS —

117	Main software
118	Enter receiver frequency
119	Enter PI code
120	Enter Capcodes
121	Filter messages
121	Store messages
122	Alarm functions
123	System control

62
63

Block Diagram
Receiver

Figure 3




FIGURE 4